


I ISTRUZIONI DI MONTAGGIO KT202/R KT204/R (KT206/R)
 GB ASSEMBLY INSTRUCTIONS KT202/R KT204/R (KT206/R)
 D MONTAGEANWEISUNGEN KT202/R KT204/R (KT206/R)



F INSTRUCTIONS DE MONTAGE KT202/R KT204/R (KT206/R)
 E INSTRUCCIONES DE MONTAJE KT202/R KT204/R (KT206/R)
 P INSTRUÇÕES DE MONTAGEM KT202/R KT204/R (KT206/R)

KT204/R



KT202/R

IS126 Rev.01
30/11/2015



	"H" mm
SERIE R20/300	60
SERIE M20	60
SERIE E20	60
SERIE G20	47

